



SCH1C

SIRIUS SATELLITE RADIO CONNECT TUNER

Installation Guide



Congratulations on your purchase of the SIRIUS Connect SCH1C Satellite Radio Tuner!

Your new SCH1C SIRIUS Connect Tuner is designed to work with SIRIUS-ready receivers. Check the SIRIUS website for model compatibility.

What is SIRIUS Satellite Radio?

110 channels of the best entertainment and completely commercial-free music for your car, home or office.

Only SIRIUS has 65 original music channels, from today's hits to R&B oldies to classical masterpieces. From authentic Country and real Bluegrass to cool Jazz, hot Latin, Reggae, Rock and many more. Best of all, it's all completely commercial-free.

SIRIUS also has 45 channels of world-class sports, news and entertainment. Coupled with great sports news from ESPN, the SIRIUS sports offering is unrivaled. And don't forget a host of other great news and entertainment, like NPR, CNBC, CBC, Radio Disney and E! Entertainment Radio. SIRIUS Canada's lineup includes 10 Canadian channels featuring some of the best of CBC Radio One programming and cutting edge Canadian indie music.

With SIRIUS, the emphasis is on the music and entertainment you want. The music is hosted by SIRIUS Jockeys, who are true experts. They back-up the music with compelling information about the song being played, and they understand that sometimes it's best to just let the music speak for itself.

Rely on SIRIUS rocket science for superior coverage.

Only SIRIUS has **three** powerful satellites that fly directly over North America ensuring coast-to-coast-to-coast coverage with high elevation angles. This gives the satellites a "clear line of sight" to your car or home, with much less concern for buildings, trees or other objects that might block conventional satellite signals.

Once you experience our 110 channels of digital entertainment, you'll never want to leave your home. For more information, visit www.siriuscanada.ca.



Table of Contents

Package Contents	3
Warnings and Cautions	4
Installation	5
Mounting the SCH1C Tuner	5
Installing the Antenna	5
Wiring the SCH1C Tuner	7
Activating Your SIRIUS Subscription	7
Operation	8
Specifications	9
12 Month Limited Warranty	11


Package Contents

- A** SCH1C SIRIUS Connect Tuner
- B** Windowsill Antenna
- C** AC Power Adapter
- D** DIN Cable

A



C



B



D





WARNING

This symbol means important instructions. Failure to heed them can result in serious injury or death.

Any function that requires your prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in an accident.

DO NOT OPEN, DISASSEMBLE OR ALTER THE UNIT IN ANY WAY. Doing so may result in fire, electric shock or product damage.

DO NOT INSERT ANY OBJECTS INTO THE UNIT. Doing so may result in fire, electric shock or product damage.

MAKE THE CORRECT CONNECTIONS. Failure to make proper connections may result in fire or product damage.

DO NOT SPLICE INTO A ELECTRICAL CABLES. Never cut away cable insulation to supply power to other equipment. Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock.

DO NOT INSTALL THE UNIT IN AREAS WHERE THERE ARE HIGH LEVELS OF HUMIDITY, MOISTURE OR DUST. Doing so can result in electric shock or product failure.

FCC Warning: This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in this User Guide. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

Note: This equipment has been tested and found to comply with Part 15 of the FCC Rules. These rules are designed to provide reasonable protection against harmful interference. This equipment may

cause harmful interference to radio communications if it is not installed and used in accordance with these instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of more of the following measures:

- Relocate the receiving antenna.
- Consult the dealer or an experienced technician for help.



CAUTION

This symbol means important instructions. Failure to heed them can result in injury or material property damage.

HALT USE IMMEDIATELY IF A PROBLEM APPEARS. Failure to do so may cause personal injury or damage to the product. Return the tuner to your authorized retailer or nearest service center for repairing.

INSTALL THE WIRING SO THAT IT IS NOT CRIMPED OR PINCHED BY SCREWS OR SHARP METAL EDGES. Route the cables away from moving parts or sharp pointed edges. This will prevent crimping and damage to the wiring. If the wiring must pass through a metal hole, be sure to use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole.

USE THE SPECIFIED ACCESSORY PARTS AND INSTALL THE PRODUCT SECURELY. Be sure to use only the specified accessory parts. Use of non-specified parts may damage this unit internally or may not securely install the unit in place. This may cause parts to become loose, resulting in hazards or product failure.

Installation

It is recommended that prior to starting the installation, you read this installation section completely and follow the instructions. In addition, consult the manual of the audio device to which you will be connecting the SCH1C Tuner to determine the required installation configuration:


- If power for the SCH1C Tuner is not provided by your audio device via the DIN cable connection, you will need to use the provided AC Power Adapter to provide power for the SCH1C Tuner.
- If audio input from the SCH1C Tuner is not supported via the DIN cable connection of your audio device, you will need to connect the audio output of the SCH1C Tuner to your audio system via the RCA-type or Optical audio output connectors of the tuner. (You will need to purchase the appropriate cable separately.)

Mounting the SCH1C Tuner


Consider the mounting location carefully to be sure that you avoid the following:

- Any location where the tuner is exposed to moisture.
- Any location where the tuner is exposed to extreme heat.

The tuner may be mounted on a wall with #10 screws, using the slots on the underside of the tuner to hang on the tuner on the screws. Alternately, the tuner may



be placed on any flat surface.



Installing the Antenna

Proper installation of the windowsill antenna is important for consistent satellite signal reception.

For correct operation and best reception of the SIRIUS signal, it is important that the antenna is located in a place where it will have a clear view of the SIRIUS satellites in the sky. Obstructions such as bushes, trees, other homes or buildings, overhangs, soffits, chimneys, gables, dormers, etc., will impair or prevent the antenna from receiving a signal.

The best reception is obtained if the antenna is located outside, and where the pod portion of the antenna (where the SIRIUS logo is printed) has a clear 360 degree view of the sky.

If you cannot obtain a clear 360 degree view of the sky outdoors, or you will be locating the antenna indoors, then you will need to place the antenna in a window (or outdoor location) which has a clear view of the sky in the direction of the satellites, and aim the antenna in the direction of the satellites, as shown in the diagram on the previous page.

Use the map in the diagram on the previous page to find the area in which you are located (1 to 5). Then find the direction in which you need to have a window (or outdoor location) with a clear view of the sky:

Area 1: You will need a window/location with a clear view of the sky facing **EAST or NORTHEAST or SOUTHEAST**

Area 2: You will need a window/location with a clear view of the sky facing **NORTH or NORTHEAST**

Area 3: You will need a window/location with a clear view of the sky facing **NORTH or NORTHWEST**

Area 4: You will need a window/location with a clear view of the sky facing

WEST or NORTHWEST or SOUTHWEST

Area 5: You will need a clear view of the sky facing **STRAIGHT UP** (Antenna cannot be located indoors)

For example, suppose you live in **Area 2**. You determined that your antenna will need to have a window (or outdoor location) with a clear view of the sky facing **North or Northeast**. The exact direction is determined by your specific location in **Area 2** relative to the **X** on the map; If you live in Winnipeg, you will need a more **South** facing clear view of the sky whereas if you live in Vancouver, you will need a more **South** facing clear view of the sky.

When you have installed the antenna in a suitable location, check the signal strength display of the receiver to verify that you are receiving a suitable signal. (Consult the user guide of your receiver for instructions on how to access the signal strength display.) A minimum of 3 bars of either satellite (SAT) or terrestrial (TER) signal strength is required for consistent reception. If you are not obtaining at least three bars, try adjusting the antenna by changing the aiming in small increments to see if you can obtain better signal reception. When you have installed the antenna in a suitable location, check the signal strength display of the receiver to verify that you are receiving a suitable signal. (Consult the user guide of your receiver for instructions on how to access the signal strength display.) A minimum of

3 bars of either satellite (SAT) or terrestrial (TER) signal strength is required for consistent reception.

If you are not obtaining at least three bars, try adjusting the antenna by changing the aiming in small increments to see if you can obtain better signal reception.

Wiring the SCH1C Tuner

The SCH1C Tuner should be wired as shown in the diagram below, using the supplied DIN cable.

Note that the AC Power Adapter is used only when your SIRIUS-ready receiver does not supply power to the tuner via the DIN cable connection. Also, if your SIRIUS-ready receiver does not support audio input via the DIN cable connection, then the audio output may be connected to your sound system using the RCA-type audio connections, or the optical cable link on the tuner.

Please consult your audio equipment manuals for the wiring connections needed for the SCH1C Tuner to operate with your particular equipment.

Activating Your SIRIUS Subscription

You must activate the SCH1C Tuner before you can begin to receive the


SIRIUS Satellite Radio service.

In order to activate your radio subscription, you will need the SIRIUS ID (SID) which uniquely identifies your tuner. The SID may be found on a sticker located on the SCH1C packaging, or on the bottom of the tuner itself. The label will have printed on it a 12-digit SID number. When you have located the SID, write it down in the space provided near the end of this manual.

To activate your subscription, call SIRIUS toll-free at:

1-888-539-SIRIUS (1-888-539-7474).

Once the subscription process is completed, your SCH1C Tuner is ready to use. Refer to the owners manual for your SIRIUS-ready receiver for further instructions on how to use your SCH1C Tuner.



Operation

Consult the owners manual of your SIRIUS-ready receiver for operating instructions.

The SCH1C Tuner has an indicator light which provides basic status information about the tuner. When the tuner is first powered on, this light will be red to indicate the tuner is receiving power. After the initial power-on indication, the light will

provide the following status information:

- Steady Red:** Initial power-on indication.
- Flashing Red:** Indicates that the antenna is not connected to the Tuner.
- Steady Amber:** Indicates that the antenna is connected to the Tuner, but no signal is being received.
- Steady Green:** Indicates that the Tuner is functioning properly and receiving a good signal.

Specifications

Operational Frequencies

Satellite	2322.293/2330.207 MHz
Terrestrial	2326.250MHz

Power Requirements 5 Volts DC

Dimensions 1" x 2.6" x 3.6" (WxHxD)
26mm x 66mm x 92mm (WxHxD)

Antenna Type Windowsill

Antenna Cable Length 21' (single micro-cable)

Connector Type SMB

Audio Interface RCA-type Stereo L/R Connectors
Optical Link Connector

Audio Output 0.75v, 550 Ohm

Signal to Noise Ratio 80dB

Weight 0.1 kg. (3.5 oz.)

Included Cable 8-Pin DIN Cable

Note: Design and specifications are subject to change without notice.



12 MONTH LIMITED WARRANTY

Please write down your SIRIUS IDs in the space provided below:

SIRIUS Radio Service SID: _____
SIRIUS Customer Service: 1-888-539-7474

SIRIUS Canada Inc. (the “Company”) warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defect(s) will be replaced with new or reconditioned product (at the Company’s option) without charge for parts and labor. To obtain replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the location shown below under WARRANTY RETURN.

This Warranty does not extend to the elimination of externally generated static or noise, to correction of antenna problems, to costs incurred for installation, removal or reinstallation of the product, or to damage to tapes, compact discs, speakers, accessories, or vehicle electrical systems.

This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY’S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY’S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 48 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

WARRANTY RETURN: To obtain a replacement within the terms of this Warranty, please return product to an authorized Sirius Canada retailer or call Erikson Consumer Customer Service at (800) 567-3275 for an authorized Sirius retailer near you; proof of purchase and description of defect are required. Products to be returned to an approved warranty station must be shipped freight prepaid.



**SIRIUS Canada Inc.
135 Liberty St - 4th floor
Toronto, Ontario, M6K 1A7
1-888-539-7474
www.siriuscanada.ca**