



Step 1: Connect the Home Dock

Select a location in close proximity to your stereo system or powered speakers, and also where the cable from the Indoor/Outdoor Home Antenna can reach the Home Dock. The location should be easily accessible and provide good visibility of the display, but should not be located where it will be in direct sunlight, which will reduce the visibility of the display screen.


1. Connect the Indoor/Outdoor Home Antenna to the silver ANT connector at the rear of the Home Dock.



2. Connect the Home Power Adapter to the red Power connector at the rear of the Home Dock, and plug it into a wall outlet.





3. Place your Onyx EZ in the Home Dock.




4. Power on your Onyx EZ by pressing the Power button.

Step 2: Place and Aim the Indoor/Outdoor Antenna

1. Check the signal strength indicator on the Radio's screen. If there are 2 or 3 bars of signal strength, continue with step 3. If not, continue with step B below.
2. Access the **Signal Indicator** screen by pressing **menu** and then pressing **▼** to scroll to and highlight **Signal Indicator**. Press the **Select** button.
3. Try experimenting with the Indoor/Outdoor Home Antenna to get a feel for the reception in your location. If either the Satellite or the Terrestrial signal bar (or both) are more than half filled, you are receiving a good signal and are done aiming the antenna. Press and hold **menu** to exit the **Signal Indicator** screen. The radio should be tuned to channel 1, the XM Preview channel. Continue with step 3.
4. If you are not yet receiving a good signal, move the antenna around the room or from room to room. Aim it at different windows, try moving the antenna closer to a window, ideally one that is facing due south.



Not sure which way is south? Think about where the sun rises (in the east) and sets (in the west). Then stand so that east is to your left and you'll be facing south. Is there a window in the direction you're facing? Place the antenna on the windowsill making sure it faces the glass and not the window frame. If you are receiving a good Satellite or Terrestrial signal (or both), you're done aiming the antenna. Press and hold **menu** to exit the **Signal Indicator** screen. The radio should be tuned to channel 1, the XM Preview channel. Continue with step 3.




If you were unable to find an indoor location for the antenna, you will need to place it outdoors. Refer to "Step 2: Place and Aim the Indoor/Outdoor Home Antenna" in the User Guide for outdoor location options.

Step 3: Connect the Audio

The Home Dock can be connected to your stereo system, or to a set of powered speakers.


To Connect the Home Dock to Your Stereo System:

1. Take the provided Stereo Audio Cable and connect the single connector to the **green AUDIO** connector at the rear of the Home Dock.
2. Connect the white left and red right Stereo Audio Cable connectors ("L" and "R" are also on each respective tip) to any available input other than PHONO on your stereo system. (If your stereo's inputs are marked red and black, connect the white plug to the black input.)
3. Turn the stereo system On, and make sure you select the correct input on your stereo system for the AUX In or LINE In connection.
4. If you have connected everything correctly, and you are receiving the XM signal, you should hear the XM audio from channel 1.
5. The audio level of your Radio can also be adjusted, if necessary. Refer to "Set Audio Level" in the User Guide to adjust the audio level. Go to siriusxm.ca/guides for the Onyx EZ User Guide (with Home Kit).



To Connect the Home Dock to Your Powered Speakers:

1. Connect the powered speakers to the **green AUDIO** connector at the rear of the Home Dock.
2. Plug the powered speakers into a wall outlet.
3. Turn On the powered speakers.
4. If you have connected everything correctly, and you are receiving the XM signal, you should hear the XM audio from channel 1.
5. The audio level of your Radio can also be adjusted, if necessary. Refer to "Set Audio Level" in the User Guide to adjust the audio level. Go to siriusxm.ca/guides for the Onyx EZ User Guide (with Home Kit).



Step 4: Activate

You can either follow the general activation and subscription process or use the on-board activation guide to activate your Onyx EZ and subscribe to the XM service.

General activation and subscription process:

1. Make sure your Onyx EZ is turned on, receiving the XM signal, and tuned to XM channel 1 so that you can hear XM audio.
2. Make a note of your XM Radio ID. You can find it by selecting **Radio ID** in menu items, by tuning to channel 0, on a label on the bottom of the gift box, and on the label on the back of your Onyx EZ.



NOTE! The XM Radio ID does not use the letters I, O, S, or F.

3. To subscribe:

- Online: Go to siriusxm.ca/activate
- OR
- By phone: Call 1-888-539-7474


Activation usually takes 10 to 15 minutes after you have completed the subscription process, but may take up to an hour. We recommend that your Radio remain on until subscribed. Once subscribed, the Radio will receive and you can tune to channels in your subscription plan.

Press **▲** or **▼** to tune to other channels, and **◀** or **▶** to browse the different categories of channels. Learn what all the buttons do on the opposite side of this Quick Start Guide.

Activation guide:

For your convenience, Onyx EZ has an on-board activation guide. You can activate your radio and subscribe to the XM service by using this guide, where you will be guided step-by-step through the subscription process. To access and use the guide, simply follow these steps:

1. Turn Onyx EZ on and press the **menu** button.
2. **Activate Radio** will be highlighted. Press the **Select** button.
3. Follow the directions on each successive screen until you complete the subscription process.



*The phone number shown above may differ from the one shown on your Onyx EZ. All numbers are valid.



Onyx EZ Button Functions

Up and Down Buttons
Press to preview and tune to channels through the channel lineup; also press to scroll through lists and highlight menu items.

Left and Right Buttons
Press to search for channels by category.

Power Button
Press to turn Onyx EZ on and off.

Select Button
Press to confirm selection of highlighted items in a menu or list.

Menu Button
Press to access advanced features and configuration options; in configuration options, press and hold to return to main display screen.


FM Button
Press to access and cycle through FM presets.

Jump Button
Press to go back to the previous channel to which you were listening.


Number Buttons
Press to tune to a stored favorite channel, press and hold to store a favorite channel; also enter a channel number.

Direct Button
Press first before entering the channel number, to directly tune to a channel.

What's in the Box?




Onyx EZ Radio




Home Dock



Indoor/Outdoor Home Antenna




Home Power Adapter



Stereo Audio Cable

Onyx EZ Main Display

When listening to a channel, information about the channel and what is currently playing is displayed.



Specifications

System	Power Requirements: 110 V AC, 400 mA (max) Operating Temperature: -4°F to +140°F (-20°C to +60°C) Audio Output: 1.5 V _{rms} (max)	Indoor/Outdoor Home Antenna	Type: XM Indoor/Outdoor Connector: SMB female Cable Length: Approximately 20 ft (6.1 m)
Onyx EZ Radio	Dimensions: 4.5 in (W) x 2.4 in (H) x 0.7 in (D) 115 mm (W) x 61 mm (H) x 17 mm (D) Weight: 3.4 oz (95 g)	Stereo Audio Cable	Connectors: 1/8 in (3.5 mm) stereo male to RCA left & right Cable Length: Approximately 5.9 ft (1.80 m)
Home Dock	Dimensions: 4.1 in (W) X 1.8 in (H) X 1.7 in (D) 105 mm (W) X 45 mm (H) X 44 mm (D) Weight: 1.9 oz (54 g) Audio Connector: 1/8 in (3.5 mm) female Antenna Connector: SMB male		
Home Power Adapter	Input: 100-240 V AC, 50-60 Hz, 0.2 A Output: 5.0 V DC, 1.0 A		

SiriusXM 12-Month Limited Warranty

What This Warranty Covers

This warranty covers defects in material and workmanship for 12 months from the date of purchase by the original retail purchaser only. SiriusXM Canada Inc., at its sole option, will repair or replace the product with a new or reconditioned product without charge for parts and labour. Products replaced under this warranty become the property of SiriusXM. Replacement products are warranted to be free from defects for 30 days or the remainder of the original warranty, whichever is longer.

What This Warranty Does Not Cover

This warranty does not cover: products sold as used, as is, reconditioned or refurbished; software stored on internal or removable memory; non-rechargeable batteries, surface preparation cleaners, adhesive pads, fasteners, and ear-buds; costs incurred for installation, removal or reinstallation of the product; correction of installation problems, such as elimination of externally generated static or noise and antenna placement and aiming; defects or damage caused by alteration, improper installation or removal, use of third party accessories, mishandling, misuse, neglect, accident, power surges or acts of nature.

How to Obtain Warranty Service

To obtain warranty service, please call Customer Care at 1-888-539-7474. You will be required to provide proof of purchase and a description of the defect. You must prepay the cost of shipping the product to an approved service center.

LIMITATIONS OF LIABILITY

THE LIABILITY OF SIRIUSXM UNDER THIS WARRANTY IS LIMITED TO REPAIR OR REPLACEMENT AS PROVIDED ABOVE AND IN NO EVENT SHALL THE LIABILITY EXCEED THE PURCHASE PRICE PAID FOR THE PRODUCT. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF WARRANTY, INCLUDING BREACH OF ANY IMPLIED WARRANTY OF MERCHANTABILITY, MUST BE BROUGHT WITHIN 48 MONTHS FROM THE DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL SIRIUSXM BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED. SOME PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. This warranty gives you specific legal rights and you may also have other rights, which vary from province to province.

If you experience problems with the operation or performance of your product

DO NOT RETURN THIS PRODUCT TO YOUR RETAILER

Call Customer Care at 1-888-539-7474

siriusxm.ca

Sirius XM Canada Inc.
135 Liberty St. - 4th floor
Toronto, Ontario, M6K 1A7
1-888-539-7474

© 2017 SIRIUS XM Radio Inc.

XEZIHKQSG 170509a



Quick Start Guide

Onyx EZ Radio & Home Kit

Self installation instructions and tips are provided for your convenience. It is your responsibility to determine if you have the knowledge, skills and physical ability required to properly perform an installation. SiriusXM shall have no liability for damage or injury resulting from the installation or use of any SiriusXM or third party products. It is your responsibility to ensure that all products are installed in adherence with local laws and regulations and in such a manner as to allow a vehicle to be operated safely and without distraction. SiriusXM warranties do not cover the installation, removal or reinstallation of any product.

This Class B digital apparatus complies with Canadian ICES-003.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.